



RACEceiver Instructions for Australia

IMPORTANT:

The Legends+AU uses Channel No.18
The US Legends+ uses Channel No.10

Default Channel Selected

Frequency to use

Squelch status

Warranty:

Your RACEceiver has a one year Return to Retailer warranty provided it is undamaged. Bring your receipt and you will receive a new one.



BASIC INSTRUCTIONS:

TURN ON Press button (2) until the display lights & check it is on the right channel

TURN OFF Press button (2) until the display goes off & take the battery out

SQUELCH ON Press buttons (3) & (4) to turn on

SQUELCH OFF Press buttons (1) & (4) to turn off

SET CHANNEL: Press button (4) until the Channel number flashes

- Press button (2) to increment by 100 channels / press
- Press buttons (1) or (3) to ^ or v one channel / press & check the frequency
- Press button (4) to lock and exit select channel mode OR
- Press buttons (1) & (3) for 2 secs sets the default channel

SET Volume: Press button (1) or (3) to raise or lower after selecting channel

NOTES FOR USERS:

Never ever leave a battery in the unit between meetings it will probably leak & void your warranty

If you hear static turn the SQUELCH ON, if you still hear it, replace your earbuds or your battery

If the sound is patchy or the display keeps changing numbers – you need a new battery

If display is on & you hear nothing, set SQUELCH OFF if still silent; replace your earbuds

The RACEceiver is NOT waterproof – keep it dry; put it inside your suit or a small plastic bag

ALWAYS insert the Blue button first
NEVER force the RACEceiver into the holster



Changing the battery



Locking Tab Up
Slide Cover out



Insert Battery
Slide Cover in
Locking Tab Down